



### Easy Access Acrylic Pocket - Cable Attachment

- 1) Insert the pocket (A) into the jaws of fittings (B) and tighten with the allen-key supplied. The working side of the fitting should face the rear of the display. Be careful not to over tighten as this may damage the pocket.
- 2) Ensure that the fittings are lined upon either side of the pocket.
- 3) Fit the pocket to the cable (C) and lightly tighten the grub screws in the order shown in the left diagram.
- 5) Repeat the procedure to complete the top row of pockets. Use a spirit level to check that the pockets are level.
- 6) Repeat this procedure to fit the other pockets, leaving 50mm between each row.